

Pre-Filter Replacement Guide

Contents :

Pre-Filter Replacement 3 Steps

Step 1 : Remove the used pre-filter

Step 2 : Remove the black gasket and O-ring

Step 3 : Install the new pre filter



eSpring™
Exclusive from **Amway**

Pre-Filter Replacement 3 Steps



Step 1 : Remove the used Pre-Filter

Unscrew the nut.
Pull to remove the pre-filter.



Step 2 : Remove the black gasket & O-ring



Step 3 : Install the new pre-filter

Place the black gasket & O-ring.
Screw the nut and slide the pre-filter
onto the filter.